


## Quick Start Guide



### STEP 1. DETERMINE IF YOUR COMPUTER ALREADY HAS BLUETOOTH SOFTWARE OR HARDWARE INSTALLED.

- Look for a Bluetooth Icon  in the taskbar (usually at the lower right of the desktop screen). If it is red or gray check for a button or function key on your laptop that will turn on Bluetooth
- Look for a Bluetooth Icon in the Microsoft Windows control panel.

***If there is no Bluetooth ICON in the control panel or in the taskbar at the bottom of the desktop then proceed to Step 2.***

*Many computers have the Bluetooth stack installed but do not have factory installed Bluetooth hardware.*

- If there is a Bluetooth Icon, Click on it then go through the menus and see if it reports that Bluetooth Hardware is installed.

If no Bluetooth hardware is installed, insert the MoGo Dapter in the USB port that will provide the best fit in your laptop case. It is advisable to select a USB port where the Dapter will receive the least amount of jarring and bending when it is in the case.

- After installing the dapter restart the Bluetooth software and initiate the Search for New Hardware Wizard. Follow the pairing instructions that are provided with your MoGo mouse or other Bluetooth Device.

### STEP 2. INSTALL THE BLUE SOLEIL BLUETOOTH STACK PROVIDED WITH THE DAPTER.

- Install the software BEFORE inserting the Dapter into a USB connector  
Insert the CD and follow the installation wizard.

### STEP 3. INSTALL THE MOGO DAPTER

- Insert the MoGo Dapter in the USB port on your laptop that will provide the best fit in your laptop case.  
It is advisable to select the USB port that will receive the least amount of jarring and bending when it is in the case.  
The "Found New Hardware" wizard will find the device driver for the Dapter.  
Proceed to Step 4.

### STEP 4: PAIRING WITH BLUE SOLEIL

Open the software from the toolbar icon. A blue window will appear with a Sun in the middle

Put your MoGo Mouse or other Bluetooth device into pairing mode. ( Follow instructions included with the device)

Click on the Sun to initiate a search for all Bluetooth Devices within 30 ft.

Click on the icon of the device that appears in "Orbit" around the sun.

A box will appear around the type of service offered by the device. ( A mouse in the case of the MoGo)

Right click on the box and select " Connect" to complete the pairing process. The Bluetooth Icon in the toolbar should turn Green.

Connection will be automatic from now on. The MoGo Mouse will go to sleep if idle for more than a few minutes.  
Clicking the right of left button will wake it up.

#### MoGo Bluetooth Adaptor- FCC ID VZOMG103

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.